






TRIM-1-2

Installation Guide for Formed Fascia Extenders (With & Without Offsets)




NOTES:
 #1 - Isolate all metal parts from ACQ treated wood or other galvanically incompatible material with appropriate membrane material.
 #2 - Appliance attachments, such as lightning rods, signs, or antennae that penetrate the water seal, induce a galvanic reaction, or otherwise compromise the effectiveness of the roof edge system, shall be eliminated or isolated to prevent problems per section 8.0 of ANSI/SPRI ES-1. It is recommended that appliances be isolated from or not attached to the roof edge system. Consult the lightning protection system manufacturer for specific attachment instructions.

- A. Formed Trim Extender
10'-0" Lengths
- B. Concealed Joint Splice
4" Lengths
- C. Galvanized Anchor Cleat
10'-0" Lengths
- D. 1-1/2" SS Ring Shank Nail
at 12" o.c. (6" from ends) clip only
(Provided & Required by Manufacturer)
- E. Fascia, Coping, Extender, or Trim
(Product may vary)




STEP 1: Installing Anchor Cleat

Place the top edge of the anchor cleat level on the wall face and press cleats securely in position and nail through pre-punched holes with 1-1/2" ss ring shank nails provided. For miter application, fit into corner as required to maintain a continuous anchor cleat line. Then nail at a min. of 6.00" on center in each direction from the corner or closer at special conditions.




STEP 2: Installing Trim Miters

Locate trim miters and joint splice for the appropriate corners. Place a joint splice under each end of the miter sections. Install the miter by hooking the drip of the trim onto the drip of the cleat and rotate back until the trim is flush with the wall face. Fasten with 1-1/2" ss ring shank nails (by installer) in each pre-punched hole.




STEP 3: Installing Trim End Caps and End Terms

Install the trim by hooking the drip of the trim onto the drip of the cleat and rotate back flush with the wall face. Fasten with 1-1/2" ss ring shank nails (by installer) in each pre-punched hole.



STEP 4: Installing Trim Straight Lengths

Place a concealed joint splice in the opposite end of the installed miter or end cap. Install the trim by hooking the drip of the trim onto the drip of the cleat and rotate back flush with the wall face. Fasten with 1-1/2" ss ring shank nails (by installer) in each pre-punched hole. Allow 1/8" gap between trim sections for thermal expansion (1/4" if temperature is below 40°). Lengths of all straight pieces should be considered prior to cutting to avoid creating relatively short sections of trim adjacent to full length section. Note: there should be a joint splice at every joint.



STEP 5: Installing Product Above

Install product above trim per manufacturer's installation instructions.